ROBOfiber Top panel view

Industrial Ethernet Managed POE+ ROBOfiber

Industrial Ethernet Managed POE+

ROBOfiber

To remove unit from rail, please repeat procedure in reverse. Start by pulling out the bottom of unit from the DIN rail.

Wall mounting procedure

HGW series have DIN rail bracket mounted from factory to the rear panel of the unit. If Wall mounting is needed, please first remove the pre-installed DIN rail bracket.

Secure the wall mounting brackets to the switch as in the below diagram. You will need 4x M3 screws for the wall mounting brackets (included) and screws for wall securing that should have head diameter larger than 6mm and screw body less than 3.5mm (these screws are not included in the package)



FCC and CE markings

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate

radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

8

This is a CE class B device, intended to be used in residential. commercial or industrial applications.

Industrial Ethernet

Managed POE+ Switch Gigabit Ethernet

HGW-402LM-PSE



Ouick Installation Guide

www.robofiber.com



HGW-402I M-PSF



Rear panel view with DIN rail and wall mounting brackets

All Industrial switches from HC. HSW and HGW series have DIN rail bracket mounted from factory to the rear panel of the unit. If Wall

mounting is needed, please first remove the DIN rail bracket. If DIN

rail bracket needs to be reattached, please make sure the spring is

Top panel has terminal screw block for PWR1 and PWR2 input and M3 grounding screw.



There are two independent and redundant power inputs, marked PWR1 and PWR2. Please observe voltage polarity when wiring power to the screw block connector. Please complete wiring without hot wires and with screw block connector disconnected from switch

Installation warning

Please make sure of proper electrical grounding availability before powering up device. The unit should be grounded using either the M3 grounding screw or making sure the DIN rail installation or wall mount brackets are correctly grounded. Make sure power wires have adequate gauge for the power required by the unit to avoid risk of wires overheating and any risk of fire. As general rule, please keep power wiring on a different path from data cables and avoid crossing wires. This will reduce the risk of power surges on data ports.

located on top position when unit is vertical.

Step 1 Step 2 Please hold unit as in below image, making sure top of bracket with spring falls onto the top edge of TS-35 DIN rail

DIN rail mounting procedure



Step 1 Step 2

Rotate and snap the unit onto the DIN rail by pushing the bottom unto the TS-35 DIN rail. Unit will be secured to rail.

HGW-402LM-PSE

ROBOfiber

Industrial Ethernet Switches

Ordering Information

HGW-402LM-PSE Gigabit Ethernet Switch 4x 10/100/1000Base-Tx + 2x 1000Base-X SFP slot ports, DIN rail and Wall installation, managed with PoE+ support

Overview

The Industrial Ethernet HGW-808S switch is a high performance and reliable Ethernet device. Model is hardened for -40 to +75 C operation and has 8KV surge protection on all copper ports. Reliability is highly ranked with an MTBF exceeding 120,000 hours. All Industrial Ethernet models listed in this manual have passed IEC standards as described in the Technical Specifications table. Package includes DIN rail mounting bracket. Wall bracket and screw block power connector.

Switch front plate view

(common front view, may vary with model)



HGW-402LM-PSE (front faceplate)

Industrial Ethernet Managed POE+ ROBOfiber

Features

IEEE 802.1Q for VLAN Tagging

 VLAN ID Range VID 1 to 4094 Auto-Negotiation and Auto MDI/MDIX

48-56V DC wide power input

8kV Ethernet surge protection on all TP ports

Extreme -40 ~ +75 °C operating temperature

Store and Forward switching mechanism

DIP #4 is reserved for future development.

Function

Full-duplex and Half-duplex flow control modes

256 IGMP Groups

DIP Switch #1

LED Indicators

P1. P2

RUN & ALM

UTP Yellow

UTP Green

operating

#2

#3

Industrial Ethernet Managed POE+

ROBOfiber

Industrial Ethernet Managed POE+

dented and an estimated

chnical specifications	
Model	HGW-402LM-PSE
P ports (RJ45)	4 x 10/100/1000
SFP slots	2 x 1000
LEDs	PWR, Fiber
	LNK/ACT, UTP
	GRN/YLW
Network Protocols	CSMA/CD
Bandwidth	126
Packet buffer size	1M
Packet max. size (bytes)	9К
VAC address table size	4K
Safety	CE/LVD
	EN60950
Power input	DC 48~56V
Reverse Polarity	yes
Protection	
PoE budget	120W
Aax PoE power per port	30W
Mounting DIN rail	yes
pracket	
Mounting Wall bracket	yes
Operating Temp (°C)	-40 ~ +75
Storage Temp (°C)	-50 ~ +85
Operating Humidity	10 ~ 90% non-condensing
Dimensions (mm) *	120 x 90 x 35
Veight (g)	350
MTBF	907,476 hours @ Telcordia SR-332 Standard
Varranty	3 years
ndustrial Compliance	
EMI	FCC Part 15 Subpart B Class A. EN 55022 Class A
MS	EN 61000-4-2 (ESD) Level 3 Criteria B, EN 61000-4-3 (RS) Level 3 Criteria A, EN 61000-4-4 (EFT) Level 3 Criteria A, EN 61000-4-5 (Surge) Level 3
2	Criteria B, EN 61000-4-6 (CS) Level 3 Criteria A, EN 61000-4-8 (PFMF, Magnetic Field) Field Strength 300A/m Criteria A
/ibration	IEC 60068-2-6
reefall	IEC 60068-2-32
hock	IEC 60068-2-27
Rail Traffic	EN 50121-4
Traffic Control	NEMA-T52
	FPs inserted, nor power block connectors

* dimensions are taken with no SFPs inserted, nor power block connectors

 IEEE 802.3 10Base-T. 802.3u 100Base-TX. 802.3z 1000Base-T IEEE 802.1w for Rapid Spanning Tree Protocol IEEE 802.1p for Class of Service

· DIN rail or Wall mount installation options, IP40 rated housing

100/1000M Adaptive)

RSTP Enable/Disable (Default: Enable)

VLAN Enable/Disable (Default: Disabled) SFP port fixed speed. ON as 100M (Default:

Off-No power available; On-Power is present Fiber LK/ACT LINK Off-No link; On-Fiber link OK; Blinking-data traffic present

Off-10M/100M; On-1000M on RI45 port Note: Gigabit models require approx. 10 seconds from "Power On" to start

3

Run ON - system OK: Alm ON - one power has failed

Off-No link; On-UTP link OK; Blinking-data traffic present

5